How to specify

- Using the V-easiSpec measuring tape (see inside) select the desired backrest combination model. (H1 - H4, W1 - W4)
- Go to the Adapt V600 EasiSpec® Specification Guide – available to download from www.ergochair.co.uk - This will take you step-by-step through all other available Adaptations™
- Contact us for help and specification advice. Our details are shown on the reverse of this brochure.

Head rest system options

V600 V-trak backrests offer an innovative headrest adaptation with infinite positioning possibilities! Ideal for asymmetrical profiling and specific postural and medical conditions.









- Dual pivot-point action
- 3 Pad shape/size options (incorporate the blue images from as mentioned above)
- Telescopic Height Adjustment
- Adjustable wings for lateral articulation
- Easily and quickly adjustable to accommodate changing needs.





Depth adjustment



Lateral adjustment





Angle adjustment



One tool adjustment




Infinite positioning




V-Trak is a registered trademark of V-Trak Ltd. Adapt is a registered trademark of Ergochair Ltd.










How the adapt® V600 measures up





Measuring the Back Height

Increased lateral support can be

achieved by selecting a deeper

The wrap

contour option

Placing the bottom of the V-EasiSpec measuring guide at the seat surface, where indicated, run it up the spine to the C7 position (vertebra prominens)

Select which of the printed scales best matches the back height and axilla height, also bearing in mind the lumbar height preference. Select the corresponding back height option H1 - H4

Place centre line of V-EasiSpec measuring

Measure the width at two points:

Measuring the Back Width

• Hip to hip across the pelvis

guide across vertical line of the spine and wrap around to the desired point of body

• Across the upper back, between the armpits

Select the corresponding back width option:

W1-W4 which offers the optimum wrap support.